

3/8" Dr. Socket 10-Point for Porsche Callipers Brake Pad Screw

Item. No.: TATPCP10D9



Refer
to instructions



Wear
eye protection



Wear
protective gloves

Thank you for purchasing a our product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

SAFETY

- ✓ **WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.
- ✓ **DO NOT** use tools if damaged.
- ✓ Maintain tools in a good, clean condition for best and safest performance.
- ✓ Ensure that a vehicle which has been jacked up is adequately supported with axle stands.
- ✓ Wear approved eye protection.
- ✓ Wear suitable clothing to avoid snagging.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Ensure all pieces are returned to the case and store this in a safe, dry, childproof location.

APPLICATIONS

- ◆ 3/8" Driver
- ◆ 9mm x 10 point
- ◆ 30mm long
- ◆ Application: Porsche Cayenne, Volkswagen Touareg and Audi Q7etc
- ◆ Manufactured from Chrome Vanadium with black phosphate finish



WARNING: Please read these instructions carefully. Note the safe operational requirements, warnings and cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and or personal injury and will in validate the warranty. Please keep instructions safe for future use.